Start with indicator powered on and in normal weighing mode

| | | | |
|---|---|---|---|
| 1 | SETUP / DRAFT | Press & hold setup key | Indicator will display "tArGEt" |
| 2 | SETUP / DRAFT | Press the setup key 3 more times to display CAL | **CAL** |
| 3 | A/M lb/kg OK UNITS | Press the OK key once | **UN itS** |
| 4 | A/M lb/kg OK UNITS | Ensure unit is set to kg, press the orange WEIGH key to toggle; Press OK | **kg** |
| 5 | A/M lb/kg OK UNITS | Press OK key to enter Scale menu and select custom scale option: other | Display reads: "SCALE" |
| 6 | UNDO WEIGH | Display will show: AG-4t. Use orange WEIGH key to toggle to OtHEr | "OtHEr" |
| 7 | A/M lb/kg OK UNITS | *(CAPACITY)* Press the OK key to go to CAP & press OK | **CAP** |
| 8 | A/M lb/kg OK UNITS | Enter capacity value; use WEIGH key and DRAFT key to edit values; press OK once complete | **02000.0 kg** |
| 9 | A/M lb/kg OK UNITS | *(RESOLUTION)* At rES screen press OK and use WEIGH key to change value to desired setting (0.50 = .5 kg or 1 lb) | **rES** |
| 10 | ZERO | Use the OK key to complete custom build setup and enter calibration mode. *Please refer to AGWR-604 for Calibration instructions.* | Custom setup complete. After Cal use Zero key to save and exit. Instrument will diplay: 'SAVING' |