

AGWEIGHR QUICK CAL (K381) Calibration Procedure

SMART WEIGHING SOLUTIONS

Start with indicator powered on and in normal weighing mode

1		Press & hold setup key	Indicator will display "tArGET"
2		Press the setup key 3 more times to display CAL	
3		Press the OK key once	
4		Ensure unit is set to kg, press the orange WEIGH key to toggle; Press OK	"Kg"
5		Press OK key then Select current weigh bar	Display reads: "SCALE"
6		Display will show: AG-4t. Use orange WEIGH key to toggle	"AG-2t"
7		Press the OK key to go to zero calibration	
8		Press OK to enter live weight reading and capture zero	Display will read: 20.7 kg (flashing live weight)
9		Press OK key again to capture zero	Display will now read: 0.0 kg (flashing)
10		To save and exit press the ZERO key	